



PART NO.	DESCRIPTION
0A202	RP .062 X .375
0A206	RP .093 X .500
0A208	RP .125 X .875
0A212	RP .125 X .312
0B103	DP .125 X .375
0B201	DP .156 X .750
0B204	DP .093 X .500
0B206	DP .125 X .562
0B300	DP .125 X .375
0D206	PHS .250-28 X 1.000
0E104	FHCS 10-24 X .375
0F104	SHCS 10-24 X .750
0G101	SS 8-32 X .625
0H206	ETLW .25 ID
0J400	NUT 8-32 X .250
0J401	NUT 10-32 X .312
68033	SAFETY SPRING
82056	SAFETY DETENT
98102-1	RECEIVER
98104	BARREL
98105	BARREL EXTENSION
98106	BARREL NUT
98107	BARREL WASHER
98108-1	MUZZLE BRAKE
98109	MUZZLE BRAKE NUT
98110	RECEIVER LATCH SEAT
98112	FRONT BOLT GUIDE
98113	REAR BOLT GUIDE
98114	LR ACCESSORY RAIL COMPLETE
98202	BOLT
98203	EXTRACTOR
98204	EXTRACTOR SPRING
98205	EJECTOR
98206	EJECTOR SPRING
98207	BOLT TUBE COMPLETE
98210	BOLT HANDLE KNOB
98211	BOLT PIN
98214	COCKING PIECE SHROUD
98215	BOLT STOP
98217	FIRING PIN
98218	FIRING PIN SPRING
98219	COCKING PIECE
98302	LOWER RECEIVER
98303	SLING BUSHING
98304	RECOIL PAD
98307	TRIGGER HOUSING
98308	TRIGGER
98312	TRIGGER WEIGHT SCREW
98315	SEAR
98316	SEAR SPRING
98319	REVERSIBLE SAFETY
98322	PISTOL GRIP
98324	MAGAZINE CATCH
98325	MAGAZINE CATCH SPRING
98326	RECEIVER LATCH
98327	RECEIVER SAFETY LATCH
98328	RECEIVER LATCH SPRING
98330	CHEEK PIECE
98331	CHEEK PIECE KNOB
98333	ELEVATION SCREW
98334	MONOPOD FOOT
98335	MONOPOD LOCK KNOB
98400	FRONT ASSY PIN
98402	MAGAZINE
98403	MAGAZINE FOLLOWER
98404	MAGAZINE SPRING
98405	FLOOR PLATE RETAINER
98406	FLOOR PLATE
98407	SLING LOOP
98409	BIPOD ADAPTOR
98410	BIPOD ADAPTOR WASHER
99056	BUTTPATE INSERT
BA-5	BIPOD ASSEMBLY

BARRETT
MODEL 98B